




DC680V Vibration Anti Bark Collar User's Manual

Product Manual

Please Read this Manual Carefully Before Use



Introduction:

The intelligent Anti Bark Collar stops barking with progressively increasing sound and vibration stimulation. It is humane and safe and does not use static shock stimulation.

Easy to use and test, activated by throat vibration when dog is barking. A microprocessor distinguishes your dog's bark from other environmental noises and automatically delivers a sound and vibration after each bark.

Important Note:

When the collar is fitted correctly IT DOES NOT MOVE... If it is NOT FITTED CORRECTLY, it will go off randomly and NOT work when your dog barks.

Main Features

Rechargeable and Water Resistant Bark Collar

- Safe and short prongs
- Combined Functions: Sound and Vibration

- 7 Levels of Sensitivity for different dogs.
- Easy and Quick Testing.
- Battery Life LED Indicators.

Operating Instructions

The Mode Button is \mathbf{Q} . Press the \mathbf{Q} for 2 secs, the Green Light will come on. You turn on the collar in Sound and Vibration mode. Press the Ω for 2 secs. Green Lights will go off. You have now turned the collar off. When it is in GREEN LIGHT Mode, what the Bark

Collar actually does when Your Dog Barks:

On the 1st Bark, 1.5 Sec Beep 2nd Bark within 40 secs, 2.5 Sec Beep 3rd Bark within 40 secs, 4 Sec Beep 0.5 sec vibration 4th Bark within 40 secs. 4 Sec Beep 1 sec vibration 5th Bark within 40 secs. 4 Sec Beep 3 sec vibration 6th Bark within 40 secs. 4 Sec Beep 3 sec vibration 7th Bark within 40 secs, 4 Sec Beep 5 sec vibration.

The collar will now enter sleep mode for 1 minute If your dog does not bark within the 40 sec limit then the collar will revert back to number 1.

Charging Instructions

The collar needs to be charged when the red light continues flashing slowly for 30s, and then turns off automatcially.

1. Open the Battery Charging Rubber Cover on the Anti Bark Collar, plug one end of the cable in the charging port and connect the other end to the adaptor, computer, notebook or power bank.

(Note: please make sure that the adaptor output is 5V/500-1000mA.)

The Red Light will be steady on when charging.

- 2. Plug the Lithium Polymer Charger into an electrical power outlet of ordinary household voltage(110-230V) based on yourlocal standard.
- 3. The Green Light will be steady on when fully charged within 1.5 to 2 hours.

Putting the Collar on Your Dog:

Ensure that you have turned the collar off. Check the collar and adjust Strap to the correct length, these prongs MUST be against your dog's skin to work, If need be, shave your dogs throat to get good contact, remember it is only for a short period of time.

Place the collar around your dog's neck, it must not move, if it does then adjust and tighten the collar.

Prongs need to be either side of dog's windpipe.

Now leave the collar on your dog. Do Not turn the collar back on. Wait for 24 – 48 hours until your dog totally ignores the collar, initially they will scratch at it and just paw at it, when that completely stops we are ready to start the training.

You must be present when you turn on the collar and start the training.

Do not just leave your dog to figure it out, teach them from the start.

DO NOT UNDER ANY CIRCUMSTANCES PUT THE COLLAR ON YOUR DOG WITHOUT FIRST TESTING IT. Testing the Collar, You do not have to bark at it. Just test by scratching the rough surface of the test tool on the bark collar(as shown in the diagram) using a fingernail or pen.

First time the bark collar will emit sound.

The second time the bark collar will emit sound.

The third time the bark collar will emit sound & vibration for 1.5 seconds.

Then repeat the same process if you want to try it again. Now you have tested the collar take the sensitivity all the way down to number 1 by pressing the – button on the collar. If your dog barks and the collar does not beep, press the + button once this will increase the sensitivity to number 2, if your dog barks again and no beep, once again press the + button, continue this until the collar beeps immediately after your dogs bark.

YOUR COLLAR IS NOW SET UP CORRECTLY. Now we are going to start the Training, under no circumstances should you just put the collar on your dog and leave it them to figure out, your dog will get confused and extremely upset.

You must teach them what you expect from them. Remember every time your dog barks you give the command NO. The collar will reinforce that command. If your dog continues to bark then you give a much more forceful NO and the collar will do the same, again continuation you give a much more forceful NO! Again the collar will mimic you. This way your dog will understand that the beep means NO. The beep and vibration means NO! And the way to stop the discomfort is to stop barking. DO NOT JUST PUT THE COLLAR ON YOUR DOG AND EXPECT THEM TO UNDERSTAND WHAT IT IS SUPPOSED TO MEAN,

I WILL ADMIT SOME DOGS ARE SUPER SMART AND WILL UNDERSTAND ALMOST IMMEDIATELY, BUT WHAT IF YOUR DOG DOESN'T UNDERSTAND, HELP THEM UNDERSTAND, TEACH THEM ALWAYS.

REMOVE THE COLLAR WHEN YOUR DOG IS PLAYING.

Please remember that this collar is a behavioral aid and you do not want to be telling your dog off while they are playing.

Caution Notes:

- Do not allow your dog to chew this collar. You should also attempt to minimize scratching or clawing at the casing.
- This device is made up of plastic and electronic components that are not digestible. Consult your local vet if your dog swallows any part of this product.
- The collar is not intended for use as a restraining collar. If you are using a leash, use it with a Separate

restraining type of collar.

FAULT FINDING GUIDE

- Q. The Collar Just Keeps Going Off.
- A 1. The sensitivity is set too high. You reduce the sensitivity by pressing the minus button.
- A 2 The collar is not tight enough, please tighten the collar.
- Q. My dog shakes his head and the collar goes off.
- A. Because the collar feels unusual to your dog they will keep shaking their heads and scratching forcing the collar to activate.
- Q. My Dog Barks But the Collar Does Not Activate.
- A. Check the battery by performing a full test. If the collar tests correctly then you will need to either Increase the sensitivity of the collar. Making it more sensitive + will make it activate easier. Or the collar is too loose, please tighten the collar.
- Q. Collar will Beep but Will Not Vibrate.
- A. There is enough charge in the battery to make it beep but not vibrate. Please recharge the battery.